



2004-2008 Audi A4 (B7) Headlight Bulb Replacement

A video tutorial on how to change or replace the 2005-2008 Audi A4 headlights.

Written By: eCuration



INTRODUCTION

This video guide will show you how to replace the headlights on a 2005-2008 Audi A4.

Best to always replace both at the same time.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [10" Ratchet Extension](#) (1)
- [Universal Flex Joint](#) (1)
- [10mm Socket](#) (1)
- [Flathead Screwdriver](#) (1)
- [Phillips #2 Screwdriver](#) (1)
- [T25 Torx Screwdriver](#) (1)
- [T30 Torx Driver](#) (1)
- [Flashlight](#) (1)



PARTS:

- [Headlight Bulb](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-23 06:51:23 AM.